

1. Remove the centre console. Two screws in the glove box, one under the ashtray and one either side at the front. Unscrew and remove the gearknob and lift the console, unplug the electric window switch and place the console out of the way.
2. Remove the Centre face plate. One screw at the bottom, and one at the top directly above each eyeball vent. These are removed by passing something very sturdy between the grilles of the eyeball vent and twisting round until it 'locks' behind the ball, then pull the ball towards you with a very sharp 'snapping' motion (do not use a steady 'pulling' motion as this will cause the retaining clips to grip even tighter!). Remove the two top screws and lift off the face plate, disconnect the hazard/pop up switch wiring plug and place the face to one side.
3. Remove the three slider knobs. These are held in place with a very small Phillips screw from underneath. Remove the fan / air con knob simply by pulling it.
4. Remove the four screws, two on each side, and then un-clip the plastic front of the slider assembly.
5. Replace the fan knob legend and then, using a sharp blade, prise up the edge and then peel off the existing black slider sheet and fit the new legend in its place (remove the protective film from the new legends prior to fitting). Re-fit the front and the four screws.
6. Fit the chrome panel over the top with the self adhesive tape that is already on it. Re-fit the slider knobs and fan / air con knob.
7. Re-fit the centre face plate, making sure to remember to plug the hazard / pop-up switch back in, re-fit the eyeball vents and the centre console, again remembering to re-connect the electric window switch.
8. Check that all electrical equipment works correctly.

Scimitar International Ltd.
Unit 4, Cluster Industrial Estate
Rodney Road, Portsmouth
Hampshire, PO4 8ST
Tel: 0845 345 2384 **Fax:** 0845 345 2385
Website: <http://www.mx5parts.co.uk>

© Copyright 2002, Scimitar International Ltd.